

		2000 STEEL TOE CAP	SLIP RESISTANT	CHEMICAL RESISTANT	WATER RESISTANT	ANTI-PENETRATION	REFLECTIVE TAPE	METatarsal PROTECTION	HEAT RESISTANT UP TO 300°	SHOCK ABSORBENT	GENUINE LEATHER	MICROFIBER	NO STEEL TOE CAP	OIL RESISTANT	HACCP APPROVED	COLD RESISTANT	WELDING	NON-METALLIC	ARC FLASH	ELECTROSTATIC DISCHARGE	ANTI-STATIC	ZIP	
TRADITIONAL	RE811	CHUKKA BOOT	◆	◆						◆			◆									◆	
	RE811-BR	CHUKKA BOOT	◆	◆						◆			◆										◆
	RE380	CHUKKA SHOE	◆	◆						◆			◆										◆
	RE128	KONTRAKTA BOOT	◆	◆						◆			◆										◆
	RE128-S	KONTRAKTA SHOE	◆	◆						◆			◆										◆
	FX2-S1P	FX2 BOOT	◆	◆		◆				◆			◆										◆
	FX2-S	FX2 SHOE	◆	◆						◆			◆										◆
	FX2-CB-S1P	FX2 CHELSEA BOOT	◆	◆		◆				◆		◆	◆										◆
	FX2-CB-BR	FX2 CHELSEA BOOT	◆	◆		◆				◆		◆	◆										◆
	RE304-BK	HIKER HI BOOT	◆	◆						◆			◆										◆
	RE304	HIKER HI BOOT	◆	◆						◆			◆										◆
RE303-BK	HIKER LO SHOE	◆	◆						◆			◆										◆	
RE508 (NST)	WORKPRO SHOE		◆								◆	◆	◆										
PREMIUM	RE942	LIGHT INDUSTRIAL SHOE	◆	◆									◆									◆	
	RE0808	ENDURO-MAX SHOE	◆	◆				◆		◆			◆									◆	
	RE316	DYNAPRO SHOE	◆	◆									◆				◆					◆	
	RE424-BK	EXPEDITION HI BOOT	◆	◆	◆	◆				◆			◆									◆	
	RE424-BR	EXPEDITION HI BOOT	◆	◆	◆	◆				◆			◆									◆	
	RE425-BK	EXPEDITION LO SHOE	◆	◆	◆	◆				◆			◆									◆	
	RE506-BK	CLASSIC BOOT	◆	◆						◆			◆									◆	
	RE506-BK-NST	CLASSIC BOOT	◆	◆						◆			◆	◆								◆	
	RE204-BR	CLASSIC BOOT	◆	◆						◆			◆									◆	
	RE204-BR-NST	CLASSIC BOOT	◆	◆						◆			◆	◆								◆	
	RE203-BK	CLASSIC SHOE	◆	◆						◆			◆									◆	
	RE652-TA	CRAZY HORSE BOOT	◆	◆					◆	◆			◆									◆	
	RE652-BK	CRAZY HORSE BOOT	◆	◆					◆	◆			◆									◆	
	RE652-BR	CRAZY HORSE BOOT	◆	◆					◆	◆			◆									◆	
	RE651-BK	HAVOC BOOT	◆	◆					◆	◆			◆									◆	
	RE651-BR	HAVOC BOOT	◆	◆					◆	◆			◆									◆	
RE420-BR	HI-TOP BOOT	◆	◆						◆			◆									◆		
RE429-CH	LO-TOP SHOE	◆	◆						◆			◆									◆		
SPECIALISED	GLO830-S1P	NON-METALLIC BOOT	◆	◆		◆				◆	◆		◆					◆				◆	
	RE655072-BK	THERMOTRAK HI BOOT	◆	◆				◆	◆	◆			◆		◆	◆						◆	
	RE5174	JIGGA BOOT	◆	◆					◆	◆	◆		◆					◆	◆			◆	
	RE210-S3	CHEMITRAK S3 BOOT	◆	◆	◆	◆	◆			◆	◆		◆									◆	
	GLO68GY	HYGIENE BOOT	◆	◆		◆				◆		◆	◆									◆	
	RE608-S3	S3 TECHNICAL BOOT	◆	◆		◆	◆			◆	◆		◆							◆		◆	
	RE912	RIGGER BOOT	◆	◆		◆	◆			◆	◆		◆					◆				◆	
	RE954	MINER BOOT	◆	◆		◆	◆		◆	◆	◆		◆									◆	
	RE911-S3	BLACK HAWK S3 BOOT	◆	◆		◆	◆			◆	◆		◆									◆	
	RE801	GLIDER SHOE	◆	◆						◆		◆	◆									◆	
RE0VS	SAFETY OVERSHOE	◆	◆						◆			◆									◆		
LADIES	RE129	NALA BOOT	◆	◆					◆		◆	◆										◆	
	RE682	IMAN SHOE	◆	◆					◆		◆	◆										◆	
	RE974	ZARI SHOE	◆	◆					◆		◆	◆										◆	
	RE940	THULI CHELSEA BOOT	◆	◆					◆		◆	◆										◆	
	RE683	KITO SHOE	◆	◆					◆		◆	◆										◆	
	RE941	LIGHT INDUSTRIAL SHOE	◆	◆					◆		◆	◆										◆	